

User Manual
Instrukcja Obsługi



LED LOGO PROJECTOR 50W

F7300235

1. INTRODUCTION

THANK YOU FOR PURCHASING **LED LOGO Projektor 50W**. FOR SAFETY REASONS AND TO ENSURE THE TROUBLE-FREE OPERATION, CAREFULLY READ THE INSTRUCTIONS.

A small handy device meant for projecting symbols on surfaces of many kinds. A custom pattern (Gobo) can be easily placed inside and the projector may do really well for instance as an advertisement of a company, a shop or a product. There's also an option of regulation the sharpness of projected symbol and adjustment to the distance that we want to display it. The projection is available in either statistic or dynamic mode.

The maximum diameter of the pattern displayed from a distance of 4 m is 1.5 m.



Additional information: gobo wheel diameter (total): 38mm, pattern diameter: 25mm

2. SAFETY INFORMATION

Attention:

■ Before installing and using this equipment, please read each item of this manual carefully.

■ It is forbidden to disseminate the contents of this manual with the permission of demonstrating the scriptures.

■ This manual only provides relevant information. All contents of the manual will be changed at any time without notice.

■ Please do not modify the equipment at will unless specified in the instruction.

■ Make shure that the power supply is disconnected before the machine is installed and repaired.

■ This product is designed for indoor demonstration. Please do not use this product for a long time in humid environment.

■ Avoid contact with water droplest during use and maintenance. If you want to use it outdoors, do enough waterproof measures.

■ Installation, operation and maintenance personnel must be familiar with the product performance before they can start operation. Most of the damage is caused by unfamiliar with its performance and misoperation.

■ After use, wipe the product with clean cloth to keep dry.

WARNING!



IMPORTANT!

Do not point strong light output from other fixtures at the **LOGO PROJECTOR**, as intense illumination can damaged the parts.




Figure 2. Lenses can focused sunlight and strong light, presenting a risk of fire and damage to the fixture. Shield or shade the head if necessary.

3. PRODUCT INFORMATION

- Power supply voltage: 120-240V
- Power consumption: 50W
- Control mode: manual
- Packaging size: W-24/H-17/D-16 cm
- Weight: 2kg

4. INSTALLATION

Use the tool to remove the top 2 screw (Fig. 1) of the machine, take out the lamp holder, put the lamp in the lamp holder, and reassemble it.

4.1 Voltage specification

Input Voltage	Total Power	Frequency
120-240V	50W	50/60Hz



Fig. 1



OSTRZEŻENIE!



WAŻNE!



Nie kieruj silnego strumienia świetlnego z innych urządzeń, ponieważ intensywne oświetlenie może uszkodzić elementy maszyny.



Rysunek 2. Soczewki mogą skupiać światło słoneczne i silne światło, stwarzając ryzyko pożaru i uszkodzenia urządzenia. W razie potrzeby należy osłonić lub zasłonić głowę.

1. WPROWADZENIE

Dziękujemy za zakup urządzenia **LED LOGO Projektor 50W**. Ze względów bezpieczeństwa oraz w celu zapewnienia bezawaryjnej pracy urządzenia należy dokładnie zapoznać się z instrukcją.

Małe poręczne urządzenie służące do projekcji symboli na powierzchniach. Dzięki możliwości umieszczenia wewnątrz własnego wzoru projektor świetnie się sprawdzi np. jako reklama firmy, sklepu czy produktu. Logo należy przygotować we własnym zakresie wykonując je ze szkła lub metalu. Istnieje możliwość regulacji ostrości projektowanego symbolu i dostosowywania do odległości na jaką chcemy go wyświetlić. Projekcja jest dostępna w trybie statycznym albo dynamicznym (obróć).

Maksymalna średnica wzoru wyświetlanego z odległości 4m wynosi 1,5m.



Informacja dodatkowa: średnica tarczy Gobo
(całkowita): 38mm, średnica wzoru: 25mm

2. ZASADY BEZPIECZENSTWA

- Przed zainstalowaniem i użyciem tego sprzętu prosimy o uważne przeczytanie każdej pozycji tej instrukcji.
- Zabrania się rozpowszechniania treści niniejszej instrukcji.
- Niniejsza instrukcja zawiera tylko istotne informacje. Cała zawartość instrukcji może zostać zmieniona w dowolnym czasie bez powiadomienia.
- Proszę nie modyfikować sprzętu dowolnie, chyba że jest to określone w instrukcji.
- Upewnij się, że zasilanie jest odłączone przed zainstalowaniem i naprawą maszyny.
- Ten produkt jest przeznaczony do

demonstracji w pomieszczeniach. Proszę nie używać tego produktu przez długi czas w wilgotnym środowisku.

- Unikać kontaktu z kroplami wody podczas użytkowania i konserwacji. Jeśli chcesz używać go na zewnątrz, zapewnij wystarczająco wodoodporne otoczenie.

- Personel zajmujący się instalacją, obsługą i konserwacją musi zapoznać się z działaniem produktu, zanim będzie mógł rozpocząć pracę. Większość uszkodzeń wynika z nieznamości jego działania i nieprawidłowego działania.

- Po użyciu wytrzeć produkt czystą szmatką, aby pozostał suchy.

3. INFORMACJE O PRODUKCIE

- Zasilanie: 120-240V
- Pobór Mocy: 50W
- Sterowanie: manualne

- Wymiary [cm]: W-24/SZ-17/G-16
- Waga [kg]: 2
- Rodzaj opakowania: Karton

4. INSTALACJA

Użyj narzędzia, aby odkręcić 2 górne śruby (Fot. 1) urządzenia, wyjąć oprawę lampy, włożyć lampę do oprawki lampy i ponownie ją zmontować.

Napięcie Zasilania	Pobór Mocy	Częstotliwość zasilania
120-240V	50W	50/60Hz



Fot. 1



FLASH

F7300235

www.flash-butrym.pl